

When fitting the damper mounting bracket make sure that the wheels are pointing straight ahead and the steering damper is at half travel to allow equal movements each way when steering is turned from lock to lock.

After assembly make sure that the bracket doesn't foul anything when the steering is turned lock to lock.

GL79 Damper Bracket Fitted to Discover 2 and Range Rover



As fitted to
Discovery 2

**The mount needs
to be angled
slightly forward**
as the damper
does not run
parallel with the
drag link.



As fitted to Range
Rover P38

The bracket will
mount horizontally.