

Fir Bank Garage
Llanfair Caereinion, Welshpool, Powys.
SY21 OBH
Tel: 01938 810298
Mobile: 07831257666



GL1021 130 Hi-Cap Front of Rear Wheel Mud Shields All 130 Hi-Cap Pick Ups



Items in kit GL1021

2 Mud Shields RH & LH

8 Speed Screws



If fitting this kit to a TD5 or Puma TD4 you'll need to cut the Mud Shield to fit around the Fuel Filter. The Mud Shield has a cut line marked on the rear, use a hacksaw blade to cut this off.



Before starting to fit these shields make sure there is no mud on the outer side panel nearest the wheel arch, this will stop the shields fitting correctly.

Hold the lower shield in place, drill the holes with a 4mm drill bit and secure the shield in place with the provided speed screws. Use Grease on the screws.